



## **How to determine what SIZE HVAC Air Filter you need:**

- Look at the HVAC Air Filter you currently have in place.
  - Most filters have their size stamped on the filter edges.
    - (12x12x1 for example)
  - Take a tape measure and measure the square/rectangle area that the filter inserts into.